


4WD Car Frame



WWW.COKOINO.COM

1

IT MAY BE MORE INTERESTING

1. Parts List

1.1 Connecting/Fixing Parts

Picture	Name	Description	Qty
	screw	M3*10MM round screw	28
4	screw	M3*25 countersunk head screw	9
	screw	M3*8 countersunk head screw	3
	screw	M3*8 round screw	4
	nut	M3 nut	10
	nut	M3 self-locking nuts	9

	copper pillar	M3*20 double pass copper pillar	4
	copper pillar	M3*10 double pass copper pillar	2
	copper pillar	M3*30MM double pass copper pillar	4
	copper pillar	M3*45 double pass copper copper pillar pillar	
ASS OF ASS	battery case	18650 battery case	1
	motor	TT motor-dual axis reduction ratio 1:48	4
	bracket	TT motor metal bracket	4

	wheel	TT motor wheel	4
	acrylic	4WD car base acrylic	
	structural	structural parts	1
	parts	sauctarur purts	

1.2 Tool

Picture	Name	Description	Qty
5) 5 G	wrench	M3 Simple Wrench	1
	screwdriver	M3 Phillips screwdriver	1

2. Assemble and Install

2.1 Assembly steps

Note: 1. Before assembly, we need to use a screwdriver to peel off the protective paper of the acrylic structure;


Step	1	Assen	nble the bracke structure A	et and the	Tool	M3 Phillips screwdriver
	Part Name	Quantity	Unit		Pi	cture
	structure A	1	PCS			
List	bracket	4	PCS		6 6	
	M3 self-locki ng nut	8	PCS		00000	00000
	M3*10 round head screw	8	PCS			

		Description	1	Demo
A	M3 self-lo bracket on a	ocking nuts the structural	ad screws and to fix the member A; installation	
Step	2	Ir	estall the TT mo	otor Tool M3 Phillips screwdriver
	Part Name	Quantity	Unit	Picture


List	Step 1 part	1	PCS	
	TT motor	4	PCS	
	M3 nut	8	PCS	
	M3*25M M screw	8	PCS	
A	install the T step 1 pa	TT motor on rt (pay atte	nd M3 nuts to the bracket of ntion to the of the TT	Demo

Step	3		Install Step struct	2 part with ure A	Tool	M3 Phillips screwdriver
	Part Name	Quantity	Unit		Pi	icture
	Step 2 part	1	PCS	(
List	M3*10 double pass copper column	2	PCS			10
	structure B	1	PCS			

	M3*8 round screw	4	PCS	
		Descriptio	n	Demo
A	 Use M3*8MM round head screws to fix the M3*10 double-pass copper column to structure A (pay attention to the installation direction of the copper column); Use M3*8mm round head screws to fix structure B on the copper column; 			





Step	4	In	stall copper pi	llars	Tool	M3 Phillips screwdriver
	Part Name	Quantity	Unit		Pi	cture
	Step 3 part	1	PCS			
List	M3*45 copper pillar	4	PCS			
	M3*30 copper pillar	4	PCS			
	M3*10 round head screw	8	PCS			
		Description	1		D	emo
A	1. Use M3*10 round head screws to fix the M3*45 copper column and the M3*30 copper column on the structural member A in turn; Pay attention to the installation direction of the copper column;					




	Structural D	1	PCS	
	M3 nut	2	PCS	
	M3*8M M screw	2	PCS	
	M3*10 round screw	4	PCS	
	Battery case	1	PCS	WAY OF ANY OF AN
	Description			Demo
A	screws to f on the stru	ix the 18650 cture C (pay ation direc	ersunk head) battery case y attention to tion of the	

- 2. Install the part completed in the previous step on the step 4 part;
- 3. Use M3*10 round head screws to fix the structural part D on the M3*45 copper column; (at the same time, pay attention to the combination of structural part C and structural part D)





	M3*20 double pass copper column	4	PCS	
	Structure E	1	PCS	
	M3*10 round head screw	8	PCS	
		Descriptio	n	Demo
A	1. Use M3*10MM round head screws to fix the M3*20 double-pass copper column to the structure E (pay attention to the installation direction of the copper column); 2. Pass the TT motor wire through the round hole of the structural member E; (not shown in the assembly tutorial) 3. Use M3*10mm round head screws to fix the part completed in the previous step on the step 5 part; 4. Install the wheels;			



Congratulations, a 4WD smart car chassis has been installed!

